## 612400

## **2009-2014 RAM 1500 W/ 2 PIECE DRIVE SHAFT**

## **CARRIER BEARING SPACER**

## **PARTS LIST:**

8368SP ALUMINUM SPACER	12
M10-1.5 X 70 HEX CAP SCREW	4
M10 FLAT WASHER	4

- 1) UNBOLT THE 4 BOLTS THAT ATTACH THE CARRIER BEARING TO THE FRAME CROSS MEMBER
- 2) INSERT 3 SPACERS PER BOLT AND RE-ATTACH THE CARRIER BEARING USING THE 4 PROVIDED BOLTS AND WASHERS

